

USR-23

Ultrasonic Active Tracking Receiver

Operation Manual



SONOTRONICS

3169 S Chrysler Ave
Tucson, AZ 85713
Email: sales@sonotronics.com
www.sonotronics.com

Updated 9/26/2023

INTRODUCTION

SONOTRONICS is a leader in the manufacture of ultrasonic tracking transmitters and receiving equipment. From its start in 1971, SONOTRONICS has earned an excellent reputation world wide for quality and performance. First to develop long-life coded ultrasonic tags, SONOTRONICS' receivers and hydrophones offer superior range and ease of use for active, passive and equipment tracking systems.

The USR-23 is an active tracking receiver, and is typically used along with a hydrophone and a pair of headphones in order to locate and identify targets while on a boat or pier or any other location that provides access to water of at least 1 meter in depth. Additionally, the integral display of the USR-23 provides ID information from ACT and Rcode transmitters, as well as decoded data from telemetry tags such as pressure or temperature, and may record these detections in its internal non-volatile memory for later retrieval. Furthermore, the rugged construction of the USR-23 and internal NiCd batteries allow operation in remote areas, away from normal power sources.

OPERATION

When operated with a directional hydrophone, the USR-23 is first preset to a particular operating frequency, then rotating the hydrophone through 360° while listening for pings with attached headphones, and repeating this procedure for each frequency of interest. The USR-23 may also be set to scan pre-selected frequencies, significantly reducing the labor involved in tracking tags utilizing multiple frequencies.

[S]

Initially when this switch is pressed, "Manual" or "Next" is displayed, depending on the current mode of the receiver. After holding this key down, the display will change to read "SCAN", and once released, the USR-23 will scan through the preset frequency list allowing hands-free tracking of multiple frequencies. A brief tone will sound every time a scan of the frequencies is complete, and a new scan is about to begin. While scanning, a momentary press of this key will cause the display to read "Manual", and upon release, the USR-23 will stop at the current frequency, allowing for prolonged tracking on this single frequency. Scanning may be resumed by again pressing and holding [S] as before, alternatively subsequent momentary presses will display "Next", and cause the USR-23 to advance, in 'single-step' fashion, through the scan list, or the FREQUENCY control knob may be turned to change to any other supported frequency. It is important to note that the LO of the USR-23 is offset by 1kHz, consequently when the receiver is set to 75kHz, a tag transmitting at 75kHz will sound in the headphone as a 1kHz note (approximately 1 octave above middle c). (Note that a setting of 32.5kHz will provide an additional 100Hz offset to allow use when listening for a Sonotronics SUR Ping and Response transducer) As in scan mode, transmissions from a tag are decoded when possible, and data is shown on the bottom line of the LCD.

[M]

When this switch is pressed quickly, "Mark" is displayed, and the USR-23 will log the time, date, frequency, ID, and associated telemetry of a detected transmitter. The USR-23 allows for storage of about 2000 such detections in the internal memory. If this key is held down, the receiver will toggle the Autostore capability to enable or disable automatic logging of tag detections.

[M]Mode

When this switch is pressed quickly, "GAIN" is displayed, and once released the FREQUENCY knob may be rotated to change the receiver gain from a value from 0 to 99. With a dual input version of the USR-23, it is possible to program different gain offsets when using the PC setup utility... this may aid tracking when using both a omni-directional hydrophone (lower gain) and a directional hydrophone (higher gain). When this switch is held, the display changes to "Setup", and the data decode type may be changed "on the fly". Its is also possible to enable or disable the internal detection beeper that sounds when the sound level of a transmitter is adequate to enable data processing.

Additionally, while pressing [Mode], if the [S] key is pressed, the internal real-time clock may be set to allow accurate time and date recording of specific detection (this time and date is held for only a few hours on non-logging versions). Furthermore, if the [M] key is pressed while holding the [Mode] key, a review of up to the last 24 detections stored in the internal EEPROM may be reviewed. While reviewing this data, subsequent toggles of [Mode] will allow progress from newest to oldest collected data.

DETECTION

When a received signal from a transmitter is of sufficient strength and duration, it is "detected" by the USR-23. The time interval between successive detections is analyzed, and pertinent data is displayed on the bottom line of the LCD. By careful use of the GAIN control of the USR-23, it is possible to both obtain telemetry information from sensing tags at long ranges, or separate signals from multiple tags transmitting on the same frequency. The GAIN setting varies how much an input signal is amplified: for tags at far distance from the receiver, the GAIN may be increased to achieve maximum amplification. Conversely, when a transmitter is very close to the receiver, or multiple tags are heard in the headphones, reducing GAIN will produce a more pleasant tone, and allow discrimination of several tags. At very close ranges, reducing the gain also increases the apparent directivity of a directional hydrophone, making locating of a target easier. In addition, in very noisy environments, detections may be increased by using a lower gain setting, thereby limiting the amount of distraction.

CONNECTIONS

Hydrophone

Please review the installation guide of the appropriate hydrophone prior to connecting it to the USR-23.

The front panel BNC connector(s) is the hydrophone input, and typically either a DH-4 directional hydrophone or TH-2 towed omni-directional hydrophone is connected. A dual-input option is available which allows for easy switching between both styles of hydrophones.

Signals received from the hydrophone may be as small as 1 microvolt, consequently care of the coax cable between the hydrophone and the USR-23 is extremely important.

Use extreme care when unwinding and winding the hydrophone coaxial cable. Your successful use of the hydrophone is dependent upon a coaxial cable in perfect condition. In the salt water environment, the smallest cut or pin hole in the coax will lead to water intrusion and failure of the unit.

The hydrophone should be laid down and the cable played out hand over hand rather than just pulling the coils off of the end. The hand over hand method eliminates kinks in the cable than can lead to it's failure. The reverse procedure should be followed when re-winding the cable.

Headphone

The headphone jack is a standard "large" (1/4 inch) stereo audio jack, and may be used with a mini-jack adapter frequently provided with stereo headphones. Note that the volume control knob on the front panel is used to control the sound level to the headphone *only*, and has no other affect on the rest of the receiving system. Choose headphones that provide adequate comfort and reduce wind noise or other sources of distraction.

Use care to avoid unnecessarily loud volume setting: during normal operation the volume control should not be set past the 12 o'clock position.

POWER

Power is supplied by 6 internal AA rechargeable NiMH batteries, and will typically operate for 8 hours on fully charged batteries. The internal NiMH are recharged via the barrel connector plug using the supplied 12VDC wall supply, or auto-power adapter, requiring 14 hours for a full charge: internal circuitry prevents the NiMH's from overcharging.

ON POWERUP

When the USR-23 is powered on, an initial status screen is displayed on the LCD:

```
USR-23vX.XX
-***  +
```

The top line identifies the firmware version number of the USR-23, while the bottom line indicates the internal battery status: a display of 1 to 5 asterisks (*) form a gauge where one "*" indicates minimum and five "*****" indicate full capacity.

SETUP MODE

To enter setup mode on the USR-23 press the “mode” switch while turning the unit on. Do not release the switch until the display reads “Setup”. Changing settings is accomplished using the “mode” button and by using the frequency knob to change the value of individual settings. The settings available to be changed are listed below:

RxMODE - After placing the USR-23 in setup mode as described earlier, the user may select “ID Tilt”, “ID %FS”, “ID Tc”, “Rcode”, or “Classic” mode. USR-23 receivers have the ability to decode ACT transmitters and associated telemetry, greatly simplifying manual tracking, and additional data decoders may be added in the future.

Scan# - This is the number of channels to be scanned. If your tags are spread from 70 to 79kHz, you would choose 10. If your tags are on 74, 78, and 80kHz, you would choose 3.

Frequency on each channel: a frequency will be displayed on the top line of the display, and the channel number will be displayed on the bottom line. You can change the frequency for this particular channel by tuning the frequency knob. When you are ready to do the next channel, simply press the next button.

SDel: This is the amount of time in seconds that the receiver will spend on each channel. “Delay 30” means that in scan mode it will spend 30 seconds on each channel before moving on the next channel. Again, use the frequency knob to change the setting, and the next button to cycle to the next parameter.

COMM: This turns off/on the com port. The USR-23 consumes more power when the com port is on, and it is only necessary when there is an external data logger attached to the USR-23.

Autostore: This turns off/on the automatic logging (storing) detections. The USR-23 contains a modest on-board memory for logging detected transmitter along with the associate date and time that the detection occurred.

Beep: This turns off/on the internal beeper. This is useful when testing transmitters in an office environment without the use of an external speaker or headphone. This may also be used to assess the level of ambient noise at a given location, and allow the setting maximum gain for long range detections.

[date/time]?: Allows setting of internal clock by using the Select knob and [Mode] key.

Fac Def: Factory Defaults. This returns the unit to the settings that it had when it shipped from our factory.

Data Retrieval

Sonotronics provides a Windows based configuration and data downloading tool to aid in integrating active and passive tracking studies. In addition, the USR-23 may be used with BLE terminal programs (such as Serial Bluetooth Terminal) to allow real-time monitoring of detections.

Specifications:

FREQUENCY RANGE: 30 to 100 kHz. (500 Hz steps)
DISPLAY: 2x16 LCD
SENSITIVITY: 1.0 microvolt for 40 dB (S+N)/N ratio.
SIZE: 9.1 x 7.6 x 4.4in (Pelican 1150 case).
WEIGHT: 3 pounds (approx).
POWER: Internal rechargeable battery with charger (6xAA).
CONNECTIONS: 0.25 inch Headphone jack, BLE, BNC hydrophone input

NOTES:



SONOTRONICS

**3169 S Chrysler Ave
Tucson, AZ 85713
Email: sales@sonotronics.com
www.sonotronics.com**

E-mail: sales@sonotronics.com
www.sonotronics.com